

ELECTRICALLY-PROGRAMMABLE TRANSISTOR ANTIFUSES

Background of the Invention

This invention relates to antifuses, and more particularly, to electrically-programmable integrated circuit antifuses and methods for programming antifuses and sensing their states.

Programmable fuses and antifuses are used in a variety of integrated circuit applications. For example, a programmable logic device may have logic that is customized by programming appropriate fuses or antifuses on the device. Fuses and antifuses may also be used to permanently switch redundant circuitry into place to fix reparable defects during the integrated circuit manufacturing process. Sometimes it may be desired to use fuses or antifuses to program a serial number or other special information into a circuit.

Fuses and antifuses may be programmed using

special laser-based systems or may be programmed electrically.

With laser programming, each fuse or antifuse must be programmed in series, so the programming process can be lengthy. The programming equipment used in laser-based systems may also be complex and expensive.

Electrically programmable fuses and antifuses are attractive because the need for laser-based programming equipment is eliminated and programming speeds can generally be increased. Such a fuse or antifuse should have a high ratio of programmed to unprogrammed resistance and should be capable of being programmed with low power in a short amount of time. For applications in which it is desired to keep the state of the fuses or antifuses secret after programming, such as when fuses or antifuses are used to store cryptographic information, it should be difficult or impossible to use diagnostic tools such as scanning electron microscopes to determine whether a given fuse or antifuse has been programmed.

It is an object of the present invention to provide improved programmable integrated circuit antifuses whose state is difficult to ascertain by reverse engineering.

Summary of the Invention

Integrated circuit transistor antifuses are provided. Circuitry and methods for programming the antifuses and sensing their states are also provided.

The antifuses may be based on metal-insulator-semiconductor transistor structures that are programmed

by breaking down a gate insulator. The transistor structures may be metal-oxide-semiconductor (MOS) structures having gate insulators formed from an oxide such as silicon oxide. The state of the gate oxide
5 (i.e., whether the gate oxide is intact or has been blown) is difficult to detect using reverse engineering tools such as scanning electron microscopes. This allows the antifuses to be used in applications that require the states of the antifuses to be kept secret.

10 The gate oxide can be broken down using localized hot carriers. During programming of an antifuse, the MOS transistor structure in the antifuse is biased so that hot carriers are generated adjacent to a particular portion of the gate oxide. This breaks
15 down the gate oxide in this localized area and programs the antifuse so that it conducts current. Because the break-down effect is localized, the programming power and time required to program the antifuse can be minimized.

20 The antifuse transistor structure has source, drain, gate, and substrate terminals. To produce hot carriers at the gate to break down the gate oxide, the drain-substrate junction is reversed biased. This places the drain-substrate junction in avalanche
25 breakdown and causes an avalanche breakdown current to flow. The avalanche breakdown current of the drain-substrate junction is enhanced by injecting carriers into the substrate by forward-biasing the substrate-source junction.

30 Further features of the invention, its nature and various advantages will be more apparent from the

accompanying drawings and the following detailed description of the preferred embodiments.

Brief Description of the Drawings

5 FIG. 1 is a schematic diagram of an illustrative integrated circuit having antifuses, programming circuitry for programming the antifuses, and sensing circuitry for sensing the states of the antifuses in accordance with the present invention.

10 FIG. 2 is a circuit diagram of illustrative antifuse circuitry in accordance with the present invention.

 FIG. 3 is a cross-sectional side view of an illustrative antifuse in accordance with the present invention.

15 FIG. 4 is a circuit diagram showing the parasitic bipolar transistor formed by an illustrative metal-oxide-semiconductor antifuse transistor in accordance with the present invention.

20 FIG. 5a is a graph showing how the electric field at the gate oxide of a metal-oxide-semiconductor transistor antifuse is greater at one end of the gate than at the other during antifuse programming in accordance with the present invention.

25 FIG. 5b is a graph showing how the hot carrier concentration underneath the gate oxide is asymmetrically distributed during device programming in accordance with the present invention.

30 FIG. 6a is a graph of an illustrative programming signal that may be used to program an antifuse transistor in accordance with the present

invention.

FIG. 6b is a graph of the output voltage of an illustrative antifuse transistor circuit during programming in accordance with the present invention.

5 FIG. 7 is a cross-sectional side view of a portion of an illustrative transistor antifuse showing how certain doping regions may be used to enhance antifuse programming in accordance with the present invention.

10 FIG. 8 is a circuit diagram showing how programming circuitry may include a biasing circuit to help program the antifuse transistor in accordance with the present invention.

15 FIG. 9 is a circuit diagram showing how a biasing circuit of the type shown in FIG. 8 may be implemented using Zener diodes in accordance with the present invention.

20 FIG. 10 is a cross-sectional side view of an illustrative antifuse transistor and associated Zener diodes in accordance with the present invention.

 FIG. 11 is a circuit diagram showing how a gated diode may be used in a biasing circuit of the type shown in FIG. 8 in accordance with the present invention.

25 FIG. 12a is a schematic cross-sectional side view of an illustrative gated diode accordance with the present invention.

 FIG. 12b is a diagram showing the circuit symbol corresponding to the gated diode structure of
30 FIG. 12a.

 FIG. 13 is a circuit diagram of an

illustrative antifuse and programming circuit having biasing circuitry of the type shown in FIG. 8 that is based on a voltage divider in accordance with the present invention.

5 FIG. 14a is a top view of an illustrative device layout that may be used when fabricating an antifuse transistor in accordance with the present invention.

10 FIG. 14b is a cross-sectional side view of a transistor using a layout of the type shown in FIG. 14a in accordance with the present invention.

 FIG. 15 is a flow chart of illustrative steps involved in programming an antifuse transistor in accordance with the present invention.

15

Detailed Description of the Preferred Embodiments

 This invention relates to antifuses based on integrated circuit transistor structures ("transistor antifuses"). The invention also relates to programming circuitry and methods for programming antifuses and sensing their states.

 Programmable antifuses may be used to program (configure) portions of an integrated circuit. In their unprogrammed state, antifuses have high resistances. After programming, the antifuses become conductive. The state of an antifuse (whether programmed or unprogrammed) can be detected using sensing circuitry and used for control and data functions on the integrated circuit.

30 The integrated circuit containing the antifuses may be, for example, a programmable logic

device that has user-customizable logic. The integrated circuit may also be a microprocessor, a digital signal processor, an application specific integrated circuit, logic, memory, a digital circuit, an analog circuit with
5 programmable devices, a combination of such circuits or any other suitable integrated circuit.

The integrated circuit may be programmed by a manufacturer or by an intermediate or end user. For example, if a manufacturer desires to include a serial
10 number, certain coding, or other special information in the integrated circuit, the manufacturer can program the antifuses on the integrated circuit appropriately during the manufacturing process. As another example, a manufacturer may produce integrated circuits that
15 contain redundant circuitry. If a repairable defect is detected by the manufacturer during device testing, antifuses on the circuit may be programmed so that appropriate spare circuitry is switched into use to replace the defective circuit.

20 Programmable logic devices can be customized by users to perform desired logic functions. Such devices may be customized by programming antifuses appropriately. Programmable logic devices may also use antifuses to implement redundancy schemes or to store
25 codes, serial numbers, or other special information in a non-volatile manner as with other integrated circuits.

An integrated circuit 10 in accordance with the present invention is shown in FIG. 1. The integrated circuit 10 may have one or more power supply
30 terminals such as terminal 12 and terminal 14. Terminals such as terminal 12 may be used to supply a

positive power supply voltage (e.g., a Vcc voltage of 1.2 volts). Terminals such as terminal 14 may be used to supply a ground potential (e.g., a Vss voltage of 0 volts). Terminals 16 may be used for I/O signals (e.g.,
5 normal data signals during device operation and programming signals during device programming operations). Terminals such as terminals 16 may also be used to provide other power supply voltages (e.g., programming voltages of about 4.5-5.5 volts, an I/O
10 power supply voltage of about 3.3 volts, etc.).

The particular voltages described herein are merely illustrative. Any other suitable voltage levels may be used if desired. Moreover the polarities of the signals (positive and negative) and types of
15 semiconductor (e.g., n-type and p-type silicon) that are used are merely illustrative.

Although aspects of the invention are described using n-channel metal-oxide-semiconductor (NMOS) transistors, p-channel metal-oxide-semiconductor
20 (PMOS) transistors may be used if desired. Moreover, the insulating materials used for the gates of these devices, while typically oxide, may also be other insulating materials (e.g., nitrides, layers of both nitride and oxide, oxynitrides, or any other suitable
25 dielectric or insulator). These transistor structures are therefore sometimes referred to as metal-insulator-semiconductor (MIS) transistors and, because oxide is a particularly suitable insulator to use, these structures are often referred to as metal-oxide-semiconductor (MOS)
30 transistors.

The "metal" of the MIS/MOS transistor

structures may be formed from a pure metal or metal alloy or other suitable conductive materials (e.g., doped polysilicon, silicide, silicided doped polysilicon, etc.). Regardless of which of these
5 conductors is used, the transistor structures will still be referred to herein as MIS or MOS transistors.

MOS transistors have sources and drains. Because the labeling of the source and drain in a given MOS transistor structure is somewhat arbitrary (i.e.,
10 because the labeling can be reversed so that the source is labeled as the drain and vice versa), these terminals can be generically referred to as source-drain terminals. For clarity, the present invention is generally described in connection with a particular
15 arrangement (i.e., with one source-drain terminal labeled as being the source and the other source-drain terminal being labeled as the drain in a particular way), but, if desired, the source and drain labels of the source-drain terminals could be reversed.

20 Moreover, although described in the context of a silicon-based arrangement, integrated circuit 10 may be based on any suitable semiconductor. For example, the substrate material from which circuit 10 is formed may be a semiconductor such as silicon (or silicon-on-
25 insulator), silicon germanium, gallium arsenide, indium phosphide, combinations of such materials, etc. These substrate materials are typically processed while in the form of wafers and are subsequently divided into individual circuits 10 prior to packaging.

30 The circuitry of integrated circuit 10 is interconnected by a number of layers of circuit

interconnections. These interconnect layers include patterned conductors and insulators. The conductors in the interconnects on circuit 10 serve to route signals between various devices on circuit 10. The insulators
5 serve to electrically isolate the conductors from each other and from the devices formed in the substrate. The layers of insulators and conductors in the interconnects and the antifuse structures, active devices, and associated circuitry of circuit 10 may be formed using
10 plasma deposition and etching, chemical vapor deposition, sputtering and evaporation, electroplating, ion-implantation and diffusion, thermal oxide growth, and other suitable semiconductor fabrication techniques.

In a typical modern integrated circuit there
15 are about 4-9 interconnect layers and other layers of material such as polysilicon, silicides, nitride, solder bumps, and passivation layers. For clarity, only the most relevant portions of the antifuses and associated structures are shown in the FIGS. For example,
20 insulating layers that may include multiple individual dielectric layers are generally shown as single layers of insulator. Conductors that may be based on multiple individual layers of conductive materials are generally shown as single layers of conductor.

25 As shown in FIG. 1, the programming signals and power supply signals from I/O terminals such as terminals 12, 14, and 16 may be provided to circuitry within the integrated circuit such as control circuitry 18. Control circuitry 18 may increase the voltage of
30 the power supply (if desired) and may produce programming signals at appropriate voltage and current

levels for antifuse programming. As an example, control circuitry 10 may increase the strength of low-level programming signals provided at I/O pins 16 so that the resulting strengthened signals may be used to program
5 antifuses 20.

The programmable antifuses may have associated sensing circuitry. The sensing circuitry may be used to convert the resistance of an antifuse (which may be either high or low depending on the state of the
10 antifuse) into a corresponding voltage signal (e.g., a high or low logic voltage level V_{OUT}). Each antifuse may have an associated sensing circuit. In the illustrative arrangements described herein, the sensing circuitry used to sense the states of the antifuses is shown
15 together with programming circuitry used to program the antifuses. This is, however, merely illustrative. If desired, sensing circuitry functions and programming circuitry functions may be performed using other suitable arrangements.

20 The output voltage from each antifuse sensing circuit may be applied to a corresponding controllable device (e.g., a transistor gate or gates, one or more transistor gates in a multiplexer, switch, pass transistor, or the input or control terminal of any
25 other suitable logic element or circuit component on circuit 10). Such configurable components are depicted generally as configurable circuitry 22 in FIG. 1. The configurable components may be configurable programmable logic (e.g., on a programmable logic device), may be
30 part of a memory (or a circuit that serves a memory function), may be part of a switch associated with a

redundancy scheme, or any other suitable circuitry that it is desired to configure.

If desired, the outputs V_{OUT} of the sensing circuits may be read without using them to specifically
5 configure any downstream logic. For example, if it is desired to program a serial number or other information or coding into the circuit 10, the appropriate bits may be programmed into circuit 10 by programming the antifuses accordingly. The output signals from the
10 sensing circuitry associated with the antifuses will then represent the states of the programmed antifuses. If access to the information programmed into the antifuses is desired, circuitry may be used to access and read the states of the sensing circuit outputs.

15 The antifuses of the present invention are based on metal-oxide-semiconductor (MOS) transistor structures. A metal-oxide-semiconductor transistor may have a source terminal (typically labeled S), a drain terminal (typically labeled D), a gate terminal
20 (typically labeled G), and a substrate terminal (typically labeled SUB). These terminals (also sometimes called electrodes) are formed using a conductive material such as copper or other metal, doped polysilicon, silicide, or combinations of such materials
25 and associated doped semiconductor regions.

In a MOS transistor, a gate insulator is used to electrically insulate the gate electrode terminal from an underlying channel region in the semiconductor. The gate insulator is typically formed from thermally-
30 grown silicon oxide, so the gate insulator is often referred to herein as the "gate oxide."

In antifuse structures based on MOS transistors, the gate oxide is initially intact. The gate oxide blocks current flow and creates a high resistance. During antifuse programming, the gate oxide is "blown," to form a conductive path through the gate oxide. This conductive path significantly lowers the resistance of the antifuse. An antifuse having a gate oxide that has been blown is said to be "programmed." Sensing circuitry associated with the antifuses may be used to convert the high or low resistances of the antifuses into appropriate digital signals for use by downstream circuitry on integrated circuit 10.

An illustrative antifuse circuit 24 for an integrated circuit such as integrated circuit 10 of FIG. 1 is shown in FIG. 2. Circuit 24 includes an antifuse 26, circuitry for antifuse programming, and sensing circuitry. In the illustrative arrangement of FIG. 2, transistor T1 serves as the antifuse. In FIG. 2 and the other FIGS., transistor T1 is shown illustratively as an NMOS transistor, but a PMOS transistor may be used if desired, provided that appropriate changes are made to the connections to its gate, drain, source, and substrate terminals.

Resistors 28, 30, and 32 (having respective illustrative resistances of about 40-80 k Ω , 10 M Ω , and 10M Ω) serve programming and sensing functions. During sensing, resistors 30 and 32 serve to convert the programmed or unprogrammed resistance value of transistor 26 into a corresponding logic low or high signal V_{OUT} at sensing circuit output terminal 34 during post-programming operation of circuit 10. During

programming, resistor 28 serves as a current-limiting resistor, which helps to prevent excessive current from flowing through transistor 26.

Resistor 28 is optional, but an advantage of
5 using resistor 28 to limit current flow is that this helps to prevent localized silicon melting in the antifuse transistor during programming. If the silicon in the antifuse were to melt during programming, it would make the antifuse's state easier to detect by
10 reverse engineering. This could compromise security in an environment in which it is desired to maintain the states of the antifuses (programmed or unprogrammed) a secret. By using only gate oxide programming to set the states of the antifuses 26, security is enhanced
15 considerably, because it is generally difficult or impossible to detect whether a given antifuse 26 has been programmed using the tools that are commonly available for reverse engineering (e.g., scanning electron microscopes).

20 A power supply voltage (e.g., a voltage V_{cc} of 1.2 volts) may be provided to terminal 36. A source of ground potential (e.g., a voltage V_{ss} of 0 volts) may be applied to terminal 38. Voltages V_{cc} and V_{ss} may be the same voltages that are being used by the core circuitry
25 on integrated circuit 10. As a result, these voltage may be readily available for antifuse circuit 24.

A programming voltage V_{pp} may be used to program antifuse 26. With the illustrative arrangement of FIG. 2, the programming voltage V_{pp} is generally
30 higher than V_{cc} . Such an elevated voltage V_{pp} may be provided using an external pin (e.g., one of pins 16 of

FIG. 1) or may be generated on circuit 10 using a charge pump circuit 41 or other suitable voltage-generating circuit that creates the voltage V_{pp} from a lower voltage. The V_{pp} voltage can be generated from any
5 suitable voltage including an I/O voltage (e.g., a 3.3 volt I/O supply voltage) that is higher than V_{cc} and that is used to provide power to input-output circuitry at the periphery of integrated circuit 10 of FIG. 1. The voltage V_{pp} may be, for example, 4.5-5.0 volts.

10 This voltage level is, however, merely illustrative. As device geometries change due to improvements in semiconductor fabrication technology, the programming voltages and the other signal levels and component values that are used herein will generally
15 also change.

The programming voltage V_{pp} may be provided to terminal 40 of circuit 24. A programming control circuit may be used to selectively apply the programming voltage to antifuse 26. During normal operation, the
20 programming circuit can isolate the programming voltage V_{pp} from the antifuse 26, so that the antifuse 26 operates normally (in either its programmed or unprogrammed state). During programming, the programming circuit can allow the programming voltage
25 V_{pp} to pass through to the antifuse 26 to blow its gate oxide.

With the illustrative arrangement of FIG. 2, the programming supply voltage V_{pp} is used as an input to gating transistor (pass transistor) 42. The gate of
30 transistor 42 may be controlled by appropriate control signals V_{cs} supplied at gate 44. With one suitable

arrangement, low-level programming signals (e.g., logic-level programming information) may be provided at terminal 46 of control circuit 48. The logic-level programming information may, for example, be provided
5 from external electrical programming equipment that is connected to circuit 10 through one or more of pins 16 during the configuration or programming of circuit 10 at a manufacturer as part of the manufacturing process or during the programming of circuitry 10 by an
10 intermediate user or end user.

The control circuit 48 may use the elevated programming voltage V_{pp} and the lower-level programming information signals at terminal 46 to create the corresponding programming control signals V_{cs} that are
15 provided to the control gate 44 of pass transistor 42. During programming, the output of pass transistor 42 (programming signal V_p) is provided to output terminal 50. A typical programming signal V_p has a magnitude of about 4.5 volts (i.e., a voltage V_{pp} of 5.0 volts minus
20 the threshold voltage of the pass-gate transistor T_2 , which may be about 0.5 volts). The duration of the programming signal may be about 10 ms.

In the example of FIG. 2, transistor 42 is an NMOS transistor. The V_p signal can be maintained at the
25 same level same while reducing the V_{pp} voltage if a PMOS-pass gate transistor is used in place of an NMOS transistor. Such a PMOS pass gate transistor can be turned on with the application of ground voltage to its gate 44.

30 Only a single programming pulse of about 10 ms in duration is generally required to program each

antifuse bit, so programming all of the antifuses on circuit 10 is relatively rapid. Moreover, because the power required to program each antifuse is relatively low, multiple bits may be programmed in parallel by control circuitry 18 (FIG. 1).

When antifuse transistor 26 is unprogrammed (its initial state), the resistance of transistor 26 (i.e., the resistance between drain D at antifuse terminal A1 and the source S and gate G at antifuse terminal B1 in FIG. 2) is high (e.g., 100 M Ω or more). With antifuse transistor 26 in an unprogrammed state, a negligible current therefore flows through transistor 26. This low current characteristic of the antifuse helps to lower the power dissipation through the unprogrammed antifuse circuitry on circuit 10. The high unprogrammed resistance of the antifuse transistor 26 relative to the resistance of resistor R1 causes the output voltage V_{OUT} to rise almost to V_{CC} , thereby producing a logic high signal V_{OUT} at terminal 34 of the sensing circuitry.

When antifuse transistor 26 is programmed by momentarily applying a high voltage V_p across its terminals A1 and B1, the resistance of antifuse transistor 26 drops significantly (e.g., by about four or five orders of magnitude or more). The resulting low resistance of antifuse 26 pulls the voltage on terminal 34 low, so that the output voltage V_{OUT} is at a logic low signal level.

As shown in FIG. 2, the source S and gate G of the antifuse transistor are electrically connected to each other at terminal B1, while only the drain is

connected to terminal A1. The drain D and source S are therefore not directly electrically connected to each other. As a result, when the programming voltage is applied across the terminals A1 and B1 of the antifuse transistor 26, an asymmetry develops. The asymmetry creates hot carriers at one end of the channel. The localized hot carriers at this end of the channel break down the gate oxide more rapidly and/or at lower power than would possible if a symmetric arrangement were used to stress the gate oxide. In a symmetric arrangement, the oxide would be stressed uniformly along its length, so it would not tend to fail as readily. With the present approach, in contrast, the localization of stress on the gate oxide helps to initiate the gate oxide breakdown process. Once this process starts, current flows through the gate oxide and completes the programming process.

A cross-section of an illustrative device structure suitable for implementing the antifuse transistor 26 of FIG. 2 is shown in FIG. 3. As shown in FIG. 3, the antifuse transistor 26 has a drain contact conductor 52 (labeled drain terminal D and antifuse terminal A1 in FIG. 2). The antifuse transistor 26 also has a source conductor 54. Drain terminal 52 is connected to n+ region 56 to form the drain of n-type metal-oxide-semiconductor (NMOS) transistor 26. Source terminal 54 is connected to n+ region 58 to form the source of transistor 26. Layer 72 is an insulator.

Transistor 26 has a gate (labeled G in FIG. 2) that is formed from a thin (typically 10s or 100s of angstroms thick) oxide 60 (typically thermal oxide)

covered by a polysilicon layer or other suitable conductor 62. A layer of silicide (e.g., cobalt silicide) may be deposited on top of the layer of polysilicon in gate electrode 62 to assist in forming a good contact for the gate. A layer of silicide may also be deposited on top of the drain n+ region 56 and the source n+ region 58 to assist in localizing the programming current. This reduces the total programming current needed for programming the antifuse transistor.

10 A conductor 64 lies between the gate region 62 and the source region 54. Conductor 64 electrically interconnects the gate G and source S, as shown in FIG. 2.

Resistors such as resistors R1, R2, and R3 of FIG. 2 may be formed from a layer of oxide such as the oxide layer that is referred to as the "poly-layer dielectric" in many NMOS fabrication processes and that is used to isolate poly interconnects from the substrate. A layer of shallow trench isolation (STI) may be formed under this oxide in the region of the resistors to help isolate the resistors from the substrate. The electrically active portion of the resistors may be formed from a lightly-doped (or undoped) polysilicon layer.

25 The antifuse transistor 26 of FIG. 3 may be formed in a p-well 66. The p-well region 66 may be a p-type substrate or a p-type region in a surrounding n-type region. This region 66 is referred to herein as the "substrate" of transistor 26. An associated terminal 70 makes an ohmic connection to region 66 via p+ tap 68 and is referred to herein as the SUB terminal.

The SUB terminal 70 may be connected to one end of resistor R2 (FIG. 2) by a conductive trace. The other end of resistor R2 may be connected to V_{ss} by a conductive trace. Silicide films may be deposited
5 directly under the contacts of the resistors to provide good ohmic conduction.

The conductive regions of FIG. 3 may be electrically isolated from the other layers of antifuse structure 26 by the insulating layer 72. Layer 72 may
10 be, for example, the insulating layer often referred to as "metal 1 dielectric" where metal 1 is the bottom layer of metal interconnect. Layer 72 may be formed from any suitable insulating material such as phosphosilicate glass (PSG), chemical vapor deposition
15 (CVD) oxide, or other insulating dielectric films.

The details of the construction of transistor 26 that are shown in FIG. 3 are merely illustrative. Any suitable materials system and layer structure may be used for transistor 26 if desired. For example,
20 transistor 26 may be a PMOS transistor. As another example, the resistors R1, R2, and R3 can be formed from diffusions in a suitable silicon region.

The p-type silicon substrate (well region) 66 lies between the source and drain and is normally not
25 conducting due to the two back-to-back diodes formed by the n+/p/n+ structure of the transistor 26. Before programming, the gate G is at ground, which turns the transistor 26 (T1) off. Because the transistor 26 is not conducting and because the gate oxide is intact, the
30 resistance of transistor 26 between terminals A1 and B1 in its unprogrammed state is high. The resistance of

transistor 26 may, for example, be about 100 M Ω to over 1 G Ω . The transistor T2 of FIG. 2 is also off when no programming is taking place. The output of the circuit 24 of FIG. 2 in this situation is high (i.e., $V_{OUT} \approx$
5 V_{CC}).

When it is desired to program antifuse transistor 26, a programming voltage may be applied to the drain terminal D (antifuse terminal A1) of the antifuse transistor 26. For example, logic-level
10 control signals (e.g., a 10 ms positive voltage pulse) may be applied to control circuit 48 of FIG. 2 via terminal 46. The control circuit 48 of FIG. 2 may generate a corresponding control signal V_{CS} at its output, which turns on pass transistor 42 and allows a
15 programming signal pulse V_p of magnitude V_{pp} or V_{pp} minus the threshold voltage V_T of the transistor T2 to reach drain terminal D of transistor 26.

Taking the drain voltage to the programming voltage (V_{pp} or V_{pp} minus V_T) produces a reverse bias in
20 the drain-substrate junction of transistor 26, because the substrate voltage V_{SUB} is initially grounded at V_{SS} through resistor R_2 . This reverse bias increases the size of the depletion region at the drain-substrate junction and increases the electric field 76 in the
25 vicinity of the depletion region. The depletion region boundary for the drain-substrate junction is shown by dotted line 74 in FIG. 3.

The magnitude of the programming voltage may be significantly higher than the voltage V_{CC} normally
30 used to operate the transistors on circuit 10. As a result, the reverse-biased diode formed at the drain-

substrate junction starts to experience avalanche breakdown. The reverse bias avalanche current is shown as current I_{AVAL} in FIG. 3.

During avalanche breakdown, electron-hole
5 pairs are created at the drain-substrate p-n junction and the current I_{AVAL} flows from the transistor's drain region 56 to the transistor's substrate region 66. The substrate is electrically connected to ground through p+ tap region 68 and resistor 32 (R2), so the avalanche
10 current produces a voltage drop across resistor R2 equal to the avalanche current I_{AVAL} times the resistance R2.

The depletion region's electric field E accelerates electrons 78 towards region 56 and holes 80 towards the substrate region 66 and source 58. As these
15 carriers travel through the transistor, additional carriers are freed by the avalanche breakdown effect. In addition, the voltage drop across R2 causes the substrate voltage V_{SUB} to rise. As the substrate voltage V_{SUB} reaches about 0.7 to 1 V, the substrate-source p-n
20 junction becomes forward biased. This, in turn, injects large numbers of carriers 82 into the substrate, as shown in FIG. 3.

The injected carriers 82 diffuse to the avalanche-breakdown region at the drain-substrate
25 junction and are accelerated by the electric field at the junction. The additional injected carriers from the forward-biased substrate-source p-n junction contribute to the avalanche breakdown of the drain-substrate p-n junction and serve as a source of positive feedback. In
30 effect, the source, substrate, and drain of the transistor act as the emitter, base, and collector of a

parasitic bipolar transistor, as shown in FIG. 4.
During programming of transistor 26, carriers injected
into the substrate (base) from the source-substrate
junction serve to turn the transistor on. As the
5 process progresses, the drain-substrate avalanche
current I_{AVAL} produces a significant localized
concentration of hot carriers (holes) in the vicinity
the drain region 56. These hot carriers cause the
adjacent gate oxide to break down, thereby programming
10 the antifuse.

The magnitude of the electric field through
the gate oxide and the concentration of hot holes that
are produced along the channel length in direction x
during antifuse programming are shown in FIGS. 5a and
15 5b. As shown in these FIGS., the gate oxide is stressed
significantly more in the vicinity of the drain than in
the vicinity of the source. The asymmetry of the stress
concentrates the impact of the programming operation,
which tends to lessen the overall effort required to
20 program transistor 26. The transistor 26 can generally
be programmed at powers of less than about 150 μW .

During programming, the series resistor R_3
(resistor 28 of FIG. 2) may serve as a current-limiting
resistor to prevent the programming current I_{AVAL} from
25 becoming too large and melting the silicon in the
vicinity of the drain.

The time required to program antifuse
transistor 26 is typically less than 10 milliseconds.
With one suitable approach, each antifuse is programmed
30 using a programming pulse of a fixed known duration
(e.g., a pulse with a fixed duration of 10 ms, as shown

in FIG. 6a). The transistor 26 will be programmed, and the output voltage V_{OUT} will be caused to drop to a low value in less than 10 ms, as shown in FIG. 6b.

Another suitable approach involves monitoring
5 the status of transistor 26 to detect the high-to-low transition of FIG. 6b during programming, so that the programming voltage may be reduced as soon as programming of the transistor 26 is complete. This approach can reduce the power dissipated during the
10 programming process.

One way in which to monitor the status of transistor 26 is to use a feedback path such as path 84 of FIG. 2 to monitor the output voltage of the sensing circuit. The control circuit 48 may monitor the output
15 voltage V_{OUT} using feedback path 84. As soon as the transistor 26 is programmed at time t_p , the resistance of the antifuse structure drops and the voltage V_{OUT} drops as shown in FIG. 6b. The control circuit 48 may detect this drop and (after a small circuit delay time)
20 may immediately reduce the programming voltage signal from the programming voltage (e.g., V_{pp}) to a low voltage (e.g., V_{ss}). Because the programming voltage is taken low as soon as successful programming of transistor 26 is detected, this approach reduces power
25 dissipation through the sensing circuit after the antifuse's state has been set.

It is desirable to reduce programming times and/or voltages as much as possible. Shorter programming times increase throughput. Smaller
30 programming voltages make it possible to program antifuses using readily available sources of power. For

example, smaller programming voltages may make it possible to perform programming operations using the elevated I/O voltage of about 3.3 volts that is already present on many integrated circuits operating at core
5 Vcc voltages of about 1.2 volts.

The use of the parasitic bipolar transistor behavior of the antifuse MOS transistor structure 26 to create hot carriers (holes in the NMOS example described in connection with FIG. 2) during programming helps to
10 make the programming process more efficient. During programming, the increase in the substrate voltage due to the voltage drop that develops across resistor R2 forward biases of the substrate-source junction and serves to inject carriers (electrons in the NMOS example
15 described in connection with FIG. 2) into the "base" (substrate) of the parasitic bipolar transistor. These injected carriers contribute to more impact ionization, which increases the avalanche current I_{AVAL} at the drain-substrate junction. The increased avalanche current
20 I_{AVAL} increases the current through resistor R2, which serves to forward bias the substrate-source junction even more. The positive feedback loop that is produced with this arrangement helps to ensure that the parasitic bipolar transistor in antifuse 26 is turned on strongly
25 during programming to create a significant concentration of hot carriers at the gate oxide in the vicinity of the drain.

To enhance the feedback behavior of the antifuse transistor programming circuit, the value of
30 resistor R2 can be increased. For a given value of I_{AVAL} , a larger value of R2 will produce a

correspondingly larger rise in the forward bias on the substrate-source junction, which will in turn inject more carriers into the transistor and turn it on more strongly. However, resistor R2 should not be made too
5 large, because if R2 is too large the transistor 26 will have a poor (low) value of "off resistance."

When transistor 26 is unprogrammed, its gate oxide is intact. During sensing, the transistor 26 is off. The off resistance between terminal A1 and B1
10 (FIG. 2) should generally be high, so that the ratio of off resistance to on resistance is high. A high off/on resistance ratio is desirable for reliable programming and good sensing performance.

Even when transistor 26 is off, a leakage
15 current flows through resistor R2. If R2 is too high, this small leakage current will produce a non-negligible voltage drop across R2. This will start to forward bias the substrate-source junction and turn the antifuse transistor 26 on, thereby lowering its "off" resistance.
20 Accordingly, the size of R2 and the leakage current associated with transistor 26 should be selected such that unprogrammed antifuse transistors are maintained sufficiently "off" during sensing.

There are several arrangements that may be
25 used to enhance feedback and facilitate programming without producing undesirably large values of leakage current through the transistor during sensing.

With one suitable feedback enhancement arrangement, an additional doping region is formed
30 adjacent to the drain. This type of configuration is shown in FIG. 7. In the example of FIG. 7, a p+ doping

region 57 has been formed adjacent to the n+ doping region 56. The p+ doping region may be formed, for example, by a diffusion or implantation of p+ dopant at a concentration level that is less than the n+ doping concentration level in region 56. As a result, the semiconductor in hatched overlap region 56/57 will be n-type.

As an example, region 56 may have an n-type doping concentration on the order of 10^{19} cm^{-3} , region 57 may have a doping concentration of about 10^{18} cm^{-3} , and region 66 may have a doping concentration of about 10^{17} cm^{-3} . In overlap region 56/57, the higher doping concentration of the n-type dopant makes the semiconductor in region 56/57 n-type at 10^{19} cm^{-3} . These concentrations are merely illustrative, any suitable doping concentrations may be used if desired.

The two different p+ doping concentrations (the 10^{18} cm^{-3} concentration used for region 57 and the 10^{17} cm^{-3} concentration used for region 66) create two parallel p-n junctions with the n-type drain region 56. These two parallel p-n junctions experience avalanche breakdown at different reverse-bias voltage levels. The p-n junction formed from the less heavily doped p-type region 66 and n+ drain region 56 will experience avalanche breakdown at approximately the same voltage levels experienced using the arrangement of FIG. 3. The p-n junction formed from the more heavily doped p-type region 57 and the n+ drain region 56 will break down at a lower voltage (e.g., a voltage as low as 1-2 volts).

By selecting a doping concentration for region 57 that is sufficiently high, the voltage needed to

initiate avalanche breakdown of the drain-substrate junction can be lowered. Once there is breakdown at this junction, the voltage across R2 will start to rise and the substrate-source junction will start to become forward-biased. The extra p+ doping region 57 therefore enhances feedback during programming and makes programming more efficient. The size of the heavily-doped junction region 57 may be selected so that this lowered breakdown voltage can be achieved without producing excessive leakage current when the antifuse is in its unprogrammed state.

Another suitable arrangement for enhancing feedback to facilitate programming involves the use of an external biasing circuit. This type of arrangement is shown in FIG. 8. Biasing circuit 88 can be used to apply a biasing signal to the SUB terminal of transistor 26 during programming. The biasing signal can further forward bias the substrate-source p-n junction, thereby injecting more carriers into the base of the parasitic bipolar transistor in the antifuse to turn it on. In the example of FIG. 2, resistor R2 forms a type of biasing circuit. When the current I_{AVAL} flows through R2, a positive voltage is produced at the SUB terminal, which forward biases the substrate-source p-n junction.

Another suitable bias circuit arrangement is shown in FIG. 9. In the example of FIG. 9, antifuse circuit 24 has two Zener diodes 90 between output terminal 34 and the SUB terminal of the antifuse transistor 26. During programming, the Zener diodes experience reverse breakdown at a relatively low voltage (about 1 volt). As a result, only a few volts need to

be applied to terminal 34 to start a current flowing through resistor R2. As soon as this current starts to flow, the voltage across resistor R2 rises, thereby increasing the bias voltage applied to the SUB terminal to forward bias the substrate-source junction.

Zener diodes 90 experience Zener breakdown at about one volt of reverse bias, so that when the two Zener diodes 90 are placed in series as shown in FIG. 9, they break down at about 2 volts of reverse bias voltage. Because a two-volt breakdown voltage is relatively low, the programming voltage that is used to program antifuse transistor 26 may be lower than with other approaches.

Although other numbers of Zener diodes could be used (e.g., one or three or more), two Zener diodes are generally preferred. Using only one Zener diode might produce more leakage current than desired during sensing (for unprogrammed devices), which would increase power dissipation. If three Zener diodes were to be used, the required programming voltage might be higher than desired.

With the two-Zener-diode arrangement of FIG. 9, there is enough current produced through the transistor 26 to make the substrate voltage V_{SUB} about 0.7-1 volt to forward bias the substrate-source junction and cause a high current to flow through the transistor 26.

Many modern integrated circuits use a low voltage level (e.g., 1.2 volts) to operate their "core" circuitry. Circuitry near the periphery of the integrated circuit (e.g., I/O circuitry) is used to

interface with off-chip circuitry and transmission lines. This peripheral circuitry therefore is generally powered using a higher supply voltage (e.g., 3.3 volts). If desired, this higher (e.g., 3.3 volt) I/O power supply voltage may be made available to the pass transistor 42, so that (in response to the control signals applied to its gate 44), the output of transistor 42 will provide a programming signal V_p that ranges from V_{ss} to a voltage of about 3.3 volts.

10 With this approach, it is not necessary to provide additional charge pump circuitry on circuit 10 to raise the programming voltage (although a charge pump may be used if desired to provide a higher programming voltage). Moreover, special external voltage sources and special high-voltage routing circuitry on circuit 10 need not be provided. Rather, the I/O power supply voltage that is already available for use in operating the I/O circuitry during normal operation can be reused for antifuse programming.

20 As shown in FIG. 9, transistor T2 may be a PMOS transistor. With this arrangement, the magnitude of V_p is equal to the magnitude of the power supply voltage applied to terminal 40 when the control signals at gate 44 are at ground. During sensing, the control signal on gate 44 may be taken to 3.3 volts (e.g., the I/O power supply voltage) to turn off transistor T2. An NMOS transistor may be used for transistor T2 if desired, although this will lead to a V_p that is less than the power supply voltage at terminal 40 unless the control signal on gate 44 is made larger than V_p . The power supply voltage on line 40 (from the I/O power

supply, from a charge pump or from another suitable source) can generally be lower if a p-type pass gate transistor T2 is used.

An illustrative Zener diode structure that may be used for diodes 90 is shown in FIG. 10. The diodes may be formed on silicon substrate 66 over an area of shallow trench isolation (not shown) to electrically isolate the diodes from the underlying silicon. An oxide layer 72 such as a layer of "poly-dielectric" may be formed on top of the shallow trench isolation region.

The p-n junctions of the Zener diodes may be formed using p+ regions 94 and n+ regions 92 (having doping concentrations of about 10^{19} cm^{-3}). A conductor 96 (e.g., a metal line) may be used to connect the region 94 of one diode to the region 92 of the other diode, as shown in FIG. 10. Another conductor 98 may be used to connect the Zener diodes to resistor R2. The structure of FIG. 10 is merely illustrative. Any suitable Zener diode device structure may be used if desired.

The substrate 66 that is used to form the electrically-programmable transistor antifuses and biasing circuit may be a bulk silicon substrate or a silicon-on-insulator (SOI) substrate. If substrate 66 is an SOI substrate, an oxide layer is buried beneath the surface of the silicon. The SOI oxide layer may, for example, be located in the substrate 66 where shown by the dotted lines 67 in FIG. 10.

The biasing circuit 88 of FIG. 8 may be formed using one or more gated diodes. An illustrative antifuse circuit 24 that has a gated diode 100 for

biasing the SUB terminal of antifuse transistor 26 is shown in FIG. 11. During normal operation of circuit 24 (i.e., during sensing), the gated diode 100 does not conduct in its reverse direction. As a result, the gated diode has a high resistance. If the antifuse transistor 26 is unprogrammed, the high resistance of the antifuse will cause the output V_{OUT} to go high. If the antifuse transistor 26 is programmed, the low resistance of the antifuse will cause the output V_{OUT} to go low.

When a programming voltage is applied to the antifuse transistor 26 to break down the gate oxide, a positive voltage appears across the gated diode 100 (i.e., the voltage at terminal B2 is greater than the voltage at terminal A2). This reverse biases the gated diode. The reverse-biased gated diode 100 experiences reverse-bias avalanche breakdown. The avalanche breakdown of the gated diode 100 produces an avalanche breakdown current. The avalanche breakdown current of the gated diode 100 flows through resistor R2, raising the voltage at the SUB terminal of antifuse transistor 26. This helps to forward bias the substrate-source p-n junction in the transistor 26 and helps to turn on the transistor 26 at a lower programming voltage than would otherwise be possible.

A cross-sectional side view of an illustrative gated diode 100 is shown in FIG. 12a. As shown in FIG. 12a, the diode 100 is formed from a transistor structure having a source 102 and a drain 104. A gate 106 is formed over a gate oxide 108. In the example of FIG. 12a, the gated diode 100 is based on an NMOS structure,

so the gate G is grounded. A substrate terminal SUB is connected to the substrate through a substrate tap 110. The gated diode 100 is formed by connecting terminal A2 to the substrate and by connecting the source 102 and
5 the drain 104 together to terminal B2. The corresponding circuit schematic symbol for the gated diode 100 of FIG. 12a is shown in FIG. 12b and in the antifuse circuit 24 of FIG. 11. The circuit of FIG. 11 has a single gated diode. Two or more series-connected
10 gated diodes may be used if desired.

Another arrangement that may be used for biasing circuit 88 of FIG. 8 is shown in FIG. 13. With the antifuse circuit 24 of FIG. 13, a switch 112 is used to selectively apply a bias voltage to the SUB terminal
15 of the antifuse transistor 26. The switch 112 may be formed from any suitable circuit components such as MOS transistors. Switch 112 may be controlled by control signals applied to terminal 114.

During normal (sensing) operation, a control
20 signal is applied to terminal 114 and the same signal or an associated control signal is applied to terminal 44 of transistor 42. These signals direct switch 112 to connect terminal 116 to terminal 120 and turn transistor 42 off. Terminal 116 is connected to a source of ground
25 potential V_{ss} (e.g., a source of ground potential applied to the circuit 24 from a pin 122). With transistor 42 off and with terminal 120 grounded, the output V_{OUT} at terminal 34 depends on the state of transistor 26. If antifuse transistor 26 is
30 unprogrammed, its resistance will be high and the output V_{OUT} will be high. If antifuse transistor 26 is

programmed, its resistance will be low and the output V_{OUT} will be low.

During programming, the control signals at terminals 114 and 44 turn transistor 42 on and direct switch 112 to connect input 118 to output 120. Input 118 may be connected to a source of a suitable programming voltage. The programming voltage may be applied from an external pin such as pin 124. With one suitable arrangement, the voltage supplied to terminal 118 is the same voltage level that is used to power input-output circuitry 126 on the integrated circuit 10. With another suitable arrangement, the voltage at terminal 118 is supplied from a charge pump. These are merely illustrative arrangements. Any suitable arrangement may be used to supply the voltage to terminal 118.

Because switch 112 is configured to connect line 118 to line 120 during programming, the programming voltage that is supplied to line 118 is passed to line 120. Transistor 42 is turned on, so this voltage is applied across antifuse transistor 26 to program the antifuse. Biasing of the transistor SUB terminal is accomplished using a voltage divider formed by resistors 128 and 130 (labeled R4 and R5 in FIG. 13).

With this voltage divider, a positive bias voltage is produced at terminal 132 during programming. This voltage raises the voltage of the SUB terminal relative to the source terminal S and forward biases the substrate-source junction. As an example, the voltage divider may raise the voltage of the substrate SUB to about 0.7 to 1 volt above that of the source S. This

creates a forward bias at the substrate-source junction that injects carriers into the substrate. The injected carriers help to turn the transistor 26 strongly on, thereby generating hot carriers at the gate oxide in the vicinity of the drain-substrate p-n junction. The hot carriers break down the gate oxide and program the antifuse. Any values may be used for resistors R4 and R5 that produce a suitable bias voltage at node 132. As an example, R4 may have a resistance of about 20 k Ω and R5 may have a resistance of about 10 k Ω .

Any suitable layout may be used for the antifuse transistors in integrated circuit 10. An illustrative layout that may be used for an antifuse transistor 26 is shown in FIGS. 14a and 14b. The layout shown in FIG. 14a is a top view of the transistor 26. The view of FIG. 14b is a cross-sectional side view of the FIG. 14a structure taken along the dotted line 134 of FIG. 14a.

As shown in FIGS. 14a and 14b, transistor 26 may have a single central n⁺ drain region 136. Two n⁺ regions 138 on either side of the drain region may be used to form the source. Two n⁺ polysilicon regions 140 may be used to form the gate of the transistor. The regions 140 may be silicided. The source and gate regions may be interconnected with each other and with V_{ss} using a layer of patterned conductor such as a layer of silicided doped polysilicon or a layer of metal (not shown in FIGS. 14a and 14b). P⁺ tap regions 142 may be used to provide an ohmic contact to the p⁺ substrate/well region 66. The widths of the source, drain, and gate regions may be about 1-5 microns or

other suitable widths.

The lengths of the gate regions may be about 0.2 microns or any other suitable lengths. With one suitable approach, the gate length used for antifuse transistor 26 is larger than the minimum channel length permitted by the semiconductor manufacturing process that is used to fabricate integrated circuit 10. By making the gate lengths slightly longer than the minimum size allowed by the semiconductor manufacturing process design rules (e.g., by making the gate 0.2 microns long when the minimum gate length allowed by a design rule is 0.12 microns or less), the drain-to-source leakage current of the antifuse transistor 26 when the transistor is in an off condition can be minimized.

To program the antifuse, the voltage of the substrate V_{SUB} should generally be raised to about 0.7 - 1.0 volts above the source to forward bias the substrate-source junction. When the entire substrate of the integrated circuit is electrically interconnected, capacitive loading effects tend to resist efforts to raise the substrate voltage V_{SUB} . Accordingly, a deep n-well isolation region 144 may be used to electrically isolate p-type region 66 from the rest of p-type substrate 146. As shown by dotted line 148 and n-well doping region 150, the n-type doping of the deep n-well isolation region may be extended along the surface of the structure to widen the area of isolation.

When an n-well arrangement of the type shown in FIGS. 14a and 14b is used to define a p-type substrate well portion 66, the amount of p-type substrate that needs to be brought up to the voltage 0.7

- 1.0 volts during programming is significantly reduced. This lowers capacitive loading and makes programming of the antifuse more rapid. In addition, the deep n-well can be electrically connected to the drain n+ region as shown in FIG. 14b. When the drain voltage ramps up during programming, it is capacitively coupled to the isolated p-substrate region 66 through the capacitance of the junction between the deep n-well 144 and the isolated p-substrate. This coupling helps raise the potential of the isolated p-substrate 66, which can reduce the programming voltage required for effective programming.

The behavior of avalanche-breakdown antifuse transistors has been characterized using antifuse transistors of different sizes (without deep n-well isolation region 144).

Transistors with gate widths of 2 microns and gate lengths of 0.24 microns have been observed to have off (unprogrammed) resistances of about 880 M Ω at 25C, unprogrammed resistances of about 176 M Ω at 85C, and programmed resistances of less than 1000 Ω . The programming current for a 4.5 V programming pulse was observed to be about 25 μ A for these transistors.

Transistors with gate widths of 2 microns and gate lengths of 0.5 microns have been observed to have unprogrammed resistances of 1.83 G Ω at 25C and 366 M Ω at 85C. Resistances of less than 1000 Ω have been observed for these transistors following programming. The programming current for a 4.5 V programming pulse was observed to be about 32 μ A for these transistors.

The unprogrammed (off) resistances of these

illustrative antifuse transistors is more than five orders of magnitude greater than the programmed resistances of the transistors. This provides good resolution between the high and low states at the output
5 V_{OUT} . The wide range between the programmed and unprogrammed resistance values also provides a large design window for the series resistor R_1 . As power supply voltages scale with future improvements with process technology, the change in the unprogrammed
10 resistance should not be large. In addition, the width of the antifuse transistor may be scaled down to maintain large enough unprogrammed resistances. Further improvements in antifuse performance (e.g., reduced programming voltage) may be obtained by using the deep
15 n-well isolation region 140. The voltages required for avalanche breakdown should become lower as junction depths shrink and become more abrupt due to enhancements in process technology.

Suitable programming powers for the
20 illustrative antifuses have been observed to be lower than 150 μW . Further reductions in the antifuse transistor dimensions may result in lower programming powers.

The programming time may be 10ms or less.
25 This short programming time allows many antifuses to be programmed in a relatively short time. Moreover, multiple antifuses may be programmed in parallel to further reduce the total programming time for the programming operation.

30 The behavior of an antifuse circuit arrangement having a bias circuit based on a two-diode

Zener-diode stack has also been characterized. Due to leakage current through the Zener diodes, the ratio of antifuse off resistance to on resistance is lower than when no bias circuit is used (i.e., three orders of magnitude rather than five orders of magnitude). Nevertheless, the lower programming voltage that is achieved through the use of the bias circuit may make this bias circuit approach more attractive in certain applications.

10 A flow chart of illustrative steps involved in programming the antifuse transistor 26 using an antifuse circuit 24 of the type described in connection with FIGS. 1-14 is shown in FIG. 15. At step 152, a programming voltage is applied across the antifuse. For example, in an NMOS-based antifuse arrangement, a positive voltage may be applied to the transistor's drain, while the gate and source of the transistor are grounded. The programming voltage may be generated by a charge pump or other internal circuitry or may be supplied from an external source (e.g., through a pin). With one suitable arrangement, a relatively high voltage such as the I/O power supply voltage that is already available on the integrated circuit for powering input-output circuitry on the integrated circuit may be used as the programming voltage.

25 Application of the programming voltage at step 152 raises the potential of the drain with respect to the transistor's substrate, thereby reverse biasing the drain-substrate junction and producing a reverse-bias avalanche breakdown current at the drain-substrate junction.

At step 154, while the programming voltage is being applied to the antifuse transistor and while the drain-substrate junction is reverse biased, a voltage can be applied to the transistor's substrate/well region (SUB terminal) to forward bias the substrate-to-source p-n junction. In a NMOS configuration, for example, the source may be grounded. The voltage on the SUB terminal may be raised relative to the grounded source by allowing the drain-substrate avalanche breakdown current to flow through a resistor R2 that is connected between the substrate and ground.

Forward-biasing the substrate-source p-n junction injects carriers into the substrate while the drain-substrate junction is reverse biased due to the application of the programming voltage. The injected carriers help to turn on the antifuse transistor.

Positive feedback can be created during programming. As the forward-biased substrate-source junction injects carriers into the substrate, the injected carriers increase the magnitude of the reverse-bias avalanche breakdown current at the drain-substrate junction. This increase in reverse-bias current leads to more current flowing through the resistor R2. The increase in current flowing through resistor R2 causes a corresponding increase in the voltage drop across the resistor R2, which raises the potential of the substrate with respect to the source. Because this further forward-biases the substrate-source junction, positive feedback is created.

The feedback produced during step 154 may be enhanced using an antifuse transistor structure of the

type described in connection with FIG. 7 in which multiple parallel drain-substrate junctions are formed each having a different reverse-bias avalanche breakdown voltage. The feedback of step 154 may also be enhanced
5 by using a suitable external bias circuit 88, as described in connection with the Zener-diode bias circuitry of FIGS. 9 and 10, the gated-diode bias circuitry of FIGS. 11 and 12, and the voltage-divider bias circuitry of FIG. 13.

10 The circuitry that is used to apply the programming voltage to the antifuse and that is used to apply suitable signals to the substrate terminal of the antifuse is shown as control circuitry 18 in FIG. 1. At step 156, the programming voltage and the substrate bias
15 continue to be applied to the antifuse transistor by control circuitry 18 to produce a sufficient quantity of hot carriers in the vicinity of the drain to break down the gate oxide and program the antifuse.

 When a transistor arrangement of the type
20 shown in FIGS. 14a and 14b is used for antifuse transistor 26, the hot carriers are generated at the inner portions of the split gate that are adjacent to the drain. Regardless of the particular geometry that is used for the antifuse, however, hot carrier
25 generation is asymmetric -- more hot carriers are generated at one source-drain terminal (e.g., the drain) than are generated at the other source-drain terminal (e.g., the source). As a result, the portion of the gate oxide nearest the drain-source terminal that is
30 injecting the hot carriers into the substrate (e.g., the gate oxide portion in the vicinity of the drain) is

exposed to the highest concentration of hot carriers. By stressing the gate oxide asymmetrically -- i.e., by forcing the gate oxide to break down in the region in the vicinity of the a particular drain-source terminal rather than uniformly under the entire gate, the efficiency of the programming process is significantly enhanced.

At step 158, the transistor may be monitored to determine whether programming has been completed. For example, a feedback path such as feedback line 84 of FIG. 2 may be used to monitor when the output voltage V_{OUT} changes. When it is determined that the gate oxide has broken down so that the resistance of the antifuse is in its low state, programming can be considered to be complete and the control circuitry 18 can stop applying the programming voltage and substrate voltage to the antifuse transistor. If desired, the control circuitry can apply programming pulses of fixed voltages and duration (e.g., 10 ms). When fixed voltages and durations are used, it is not necessary to monitor the antifuse transistor during programming to determine when programming is complete.

After the antifuse has been programmed using the process of FIG. 15, the sensing circuitry associated with the antifuse may be used to sense its state. There are typically numerous antifuses on a given integrated circuit. The antifuse transistors that have been programmed have low resistances, whereas the antifuse transistors that have not been programmed have high resistances. The sensing circuitry can be used to produce corresponding voltage outputs (e.g., a high

voltage signal at an output terminal such as terminal 34
when an antifuse is unprogrammed and has a high
resistance or a low voltage signal at an output terminal
such as terminal 34 when an antifuse has been programmed
5 and has a low resistance).

Because the antifuses are programmed by
breaking down a gate oxide without melting adjacent
silicon, it is relatively difficult to use tools such as
scanning electron microscopes to detect whether a given
10 antifuse has been programmed. The antifuses may
therefore be suitable for high-security applications.

The foregoing is merely illustrative of the
principles of this invention and various modifications
can be made by those skilled in the art without
15 departing from the scope and spirit of the invention.